



DIRECTIONS FOR USE

XP

Surface Preparation

Proper surface preparation is the key to maximum performance. The appearance and durability of this product can be impaired by an unsound or poorly prepared surface. It is very important that the surface be clean of all dirt, mildew, loose wood fibers and other foreign matter. Surfaces must be structurally sound. Timber Pro XP can be applied over a previously coated surface if it is in sound condition. Loose or flaking material must be removed prior to application. New wood that appears shiny must be sanded and rinsed to remove mill glaze. New rough cut lumber should be power washed. New logs must be power washed or sanded.

Precautions

Do not apply if rain or freezing temperature is likely to occur. Apply to a cool surface and avoid application in direct sunlight. Do not apply in temps above 27°C (80°F) or below 10°C (50°F). Protect from freezing.

Stirring

Stir thoroughly before and occasionally during use. If the job requires more than one batch, blend them together. Before proceeding with entire job always test for appearance and color in an inconspicuous area. To avoid non-uniform appearances: On vertical siding start at top with several boards and continue all the way to the bottom. On horizontal siding and/or logs start at bottom and work up. Start at one edge and follow through to a logical break, such as a door, window or corner.

Method of application

Best results are with a quality nylon polyester brush. Airless sprayer application is acceptable but must be immediately back brushed. Flood coat surface and then smooth out all runs, drips and puddles.

Number of Coats

For exterior surfaces apply a minimum of 2 pigmented coats allowing adequate drying time between coats (minimum 2 hours). After initial coats have dried apply a final coat of Timberpro XP Clear as a topcoat for maximum wear. For interior surfaces apply a minimum of 2 pigmented or clear coats. Apply as much product as wood will absorb on each coat.

Coverage Per Coat

On rough sawn wood coverage is between 5 - 6.1 m² per liter (200-250 sq ft per gallon). Smooth wood coverage is 6.1 - 7.4 m² per liter (250 - 300 sq ft/gallon). Exotic woods (hardwoods) coverage is between 7.4 - 9.8 m² per liter (300 - 400 sq ft / gallon). Aged porous wood requires coverage between 3.5 - 5m² per liter (150 - 200 sq ft per gallon). Coverage may vary depending on the porosity of the wood.

Maintenance

Depending upon exposure or wear, evaluate recoating needs every 2 - 4 years. Timberpro XP can be applied on an as needed basis as a topcoat and as part of an ongoing maintenance program.

Clean Up

Clean Up: Clean brushes and equipment immediately after use with soap and water.

THE COMPLETE LINE OF TIMBER PRO PRODUCTS

Timber Pro Coatings Canada
Unit 140, 12051 Horseshoe Way, Richmond BC, V7A 4V4
Tel: 604-270-4244 email: canadainfo@timberprocoatings.com

Warranty

When applied to new wood according to the label directions. If this Timber Pro product is proved to be defective after purchase Timber Pro Coatings Ltd. will furnish any necessary additional product free of charge or will refund the purchase price at the company's option. This warranty does not include labor or coat of labor. For the application of the product, this warranty gives you specific legal rights. And you may also have other rights that vary from country to country.

www.TimberProCoatings.com